



OIL CONTAINER DRAINER USER'S MANUAL

Part No. JDI-CD21

FOR WARRANTY INFORMATION, PLEASE CALL 800-433-0708

DATE OF PURCHASE: _____

READ AND SAVE THIS MANUAL

FOR SERVICE ASSISTANCE, CALL 800-433-0708 OR VISIT JOHNDOW.COM



Important Product Information


Read this manual before using this product.

Please contact your local county environmental health department to understand how to properly dispose of the automotive fluids you generate.


GETTING STARTED

Before assembly, ensure you have all parts according to the contents. If any parts are missing or damaged, contact JohnDow Industries for replacement.

CONTENTS



Item No.	Description	Qty
1	Drain Box	1
2	Drain Station	1
3	M6 x 100 Threaded Bumper	2
4	Door Brace	2
5	2" NPT to 42mm Bung Adapter, 3-piece	1
6	1-1/4" NPT x 6" Extension Tube	1



ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED: Pipe Wrench

1. Remove all contents from carton and plastic packaging. Open drain doors on Drain Box (1) and remove all components.
2. Flip drain over. Thread Extension Tube (6) onto drain port. Tighten with pipe wrench.
3. Thread Bung Adapter (5) onto used oil tank/drum port.
4. Loosen Bung Adapter to slide tube through. Adjust to desired height and hand tighten.
5. Thread together Threaded Bumper and Threaded Rod (both #3 in image above).
6. Use Threaded Bumpers (3) to slightly angle and support the drain.
7. Place Door Braces (4) in the side pockets of the Drain Box angling outward.
8. Open Drain doors and place Drain Station (2) into drain box.

OPERATION

1. Place empty oil bottles upside down on Oil Container Drainer pegs until all residual oil drains from bottles. Remove bottles and discard.

Note: the pegs on the doors are for gallon container handles.

2. When not in use, close and lock doors to prevent potential fire hazard (Lock not included).

FOR SERVICE ASSISTANCE, CALL 800-433-0708 OR VISIT JOHNDOW.COM